



Sicherheitshinweise!!!



Achtung !!! Bitte lesen Sie die Bedienungsanleitung, sowie die Sicherheitshinweise vor dem Aufbau sowie dem Gebrauch des Multi-Rollys aufmerksam durch.
Eine Garantie kann nicht erhoben werden wenn Schäden, die durch Nichteinhaltung des korrekten Zusammenbaus sowie unsachgemäßem Gebrauch des Multi-Rollys entstehen.

Achtung !! Warnhinweise

Der ECKLA Multi-Rolly **besitzt keine Bremse**, er darf daher nur auf ebenen Untergründen aufgestellt werden.

Der Multi-Rolly sollte auch nicht in der Nähe von Treppen, Abhängen, abschüssigem Gelände oder Schwimmbecken aufgestellt werden.

Der **Transport von Menschen und Tieren ist grundsätzlich verboten**.

Des Weiteren darf der Multi-Rolly **nur außerhalb öffentlicher Verkehrsflächen benutzt werden**. Er entspricht nicht der StVZO und darf im Verkehr nicht eingesetzt werden.

Der Multi-Rolly darf **nicht als Anhänger für Fahrzeuge** jeglicher Art benutzt werden.

Der Multi-Rolly muss immer zuerst vollständig auseinandergeklappt und mit dem **Sicherungssplint** gesichert werden, bevor Sie sich hineinsetzen.

Transportieren oder stellen Sie **nie geladene** Waffen im Multi Rolly ab !!!!!!!!!!!!!!!.

Lassen Sie sich nicht in den Multi-Rolly hineinfallen, sondern setzen Sie sich stets vorsichtig hinein.

Verwenden Sie nur original ECKLA Ersatzteile zur Reparatur des Multi-Rollys.

Achtung! Selbstsichernde Muttern müssen nach Demontage durch neue ersetzt werden.

Der Multi-Rolly besitzt Reifen aus vulkanisiertem Naturkautschuk, es besteht die Gefahr der Fleckenbildung im Bereich der Aufstandsflächen der Reifen. Die Kontaktflächen bitte stets schützen, besondere Vorsicht ist bei mit Lösungsmitteln verklebten Böden wie Teppich und insbesondere PVC geboten.

Wenn Sachen mit dem Multi-Rolly transportiert werden, sollten diese stets mit einem Zurrband oder ähnlichem Befestigungsmittel gegen Herausfallen gesichert werden.

Belastung:

Höchstzulässige Last beim Transport ziehend 50 kg.

Höchstzulässige Belastung als Stuhl 120 kg.



Achtung !!! Verletzungsgefahr



Im Bereich der Scharniere besteht generell Verletzungsgefahr durch Quetschung der Finger oder Hand.

Bitte halten Sie beim Hineinsetzen oder Aufstehen die Hände fern von den besonders mit dem **Warnaufkleber „Vorsicht vor Handverletzung“** gekennzeichneten Bereichen. Bitte lassen Sie Ihre **Kinder nie unbeaufsichtigt** alleine im Multi-Rolly sitzen **oder damit spielen**.



Pflege und Wartung:

Verwenden Sie zur Säuberung nur umweltfreundliche, **keinesfalls aggressive oder ätzende Reinigungsmittel**.

Schützen Sie die Sitzfläche vor starker Erwärmung durch die Sonne. Legen Sie ein Handtuch auf den Sitz um Farbe und Material zu schonen.

Nicht mit nasser Kleidung in den Multi-Rolly setzen, legen Sie bitte ein Handtuch dazwischen.

Information und Hilfe

Falls Sie Probleme mit der Bedienungsanleitung oder technischer Art bei der Benutzung und dem Gebrauch des ECKLA Multi-Rolly haben, so wenden Sie sich bitte an Ihren Fachhändler oder direkt per **e-mail** oder Telefon an

e-mail: info@eckla.de oder Telefon: 07946 / 9155 0

ECKLA GmbH, Brunnenstr. 34, 74626 Bretzfeld-Schwabbach



Remarks and Warnings !!!



WARNING!!! Please carefully read following Instructions and owners manual before assembling or using the Multi-Rolly. Serious injury can result if used improperly. Follow the owners manual for further information. Please note that the warranty does not cover damage due to negligence of assembly, adjustment or maintenance instructions described in this manual.



Warning !!!

The ECKLA Multi-Rolly has no brakes. Use the Multi-Rolly only on level ground.

Do not use the Multi-Rolly near stairs, unlevel ground, slopes, hills, or swimming pools.

The Multi Rolly should never be used as a stroller for babies or children, there are no restraints for safe transport and therefore would be dangerous .

Use of the Multi-Rolly for the transport of people or animals is strictly forbidden.

Use the Multi-Rolly in appropriate areas only, away from road traffic. This product does not comply with road traffic approval regulations and, therefore, use of the Multi-Rolly in road traffic is prohibited.

It is strictly forbidden to use the Multi-Rolly as a trailer on any kind of vehicle.

Always unfold the Multi-Rolly completely and secure with the linch pin before using it for transport or as a chair.

Do never transport or park loaded Weapons in the Multi Rolly !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!.

Do not jump into the Multi-Rolly. Always sit down slow and carefully.

Do not force parts that do not fit freely. Never interchange ECKLA Multi-Rolly components with components from a different manufacturer. Only use original ECKLA spare parts.

Warning! Always replace self-locking nuts (hard to remove) with brand new ones, if completely disassembled.

The tires of the Multi-Rolly are similar to car tires in that they contain vulcanised Indian rubber, and there is a risk that stains may form in areas where tires contact the floor. Please protect contact face between floor and tire. Handle the Multi-Rolly with care if you position it on a carpet and/or PVC floor glued together by means of a bonding agent containing solvents that will degenerate.

If you use the Multi-Rolly to transport, please take care that the transported goods are secured at all times with a tie down.

Allowed maximum weights:

Max. Load by using as a carrier	110 lbs
Max. Load by using as a chair	264 lbs



Warning !!! Danger of serious injury



Please note carefully: Serious injury can occur by getting fingers or hand caught near the area of the hinge of the stand and the back of the Multi-Rolly seat.

When sitting down or standing up from the Multi-Rolly, do not touch the areas which are signed with the black/yellow stickers “ **Warning, danger and seriously hand injure can happen**”. Never let your children play unsupervised with the Multi-Rolly or let them sit in the Multi-Rolly chair alone.



Service and Maintenance:

Use only low-pollution and mild agents for cleaning the Multi-Rolly. Protect the fabric from fading and losing strength when parked in the sun by putting a towel over the seat and back. Do not sit down in the Multi-Rolly with wet clothing. Before sitting, put a towel on the seat cover.

Help and Support

For help or additional information, or with technical problems concerning use of the ECKLA Multi-Rolly, please contact your dealer or ECKLA Germany direct per e-mail or phone.

e-mail: info@eckla.de or Phone: +49(0)7946 / 9155 0

ECKLA GmbH , Brunnenstr. 34 , 74626 Bretzfeld-Schwabbach, GERMANY